

Assembly of Profoto RFI Softboxes

1. Position the rounded rod end into the loops (picture A) and fully into the corner pocket (picture B). Color markings on the rod end should be towards center / speeding. The rod should stay in the pocket even when disassembling the softbox
2. When mounting the rods into the speeding, make sure to match the rod color with the same color on the speeding (picture C).
3. Align the rods with the holes by slightly bending the rods (picture D). By slightly bending the opposite rod against your leg or the floor the tension on the softbox will decrease and mounting gets easier. Repeat the procedure when disassembling the softbox.
4. Tight the softbox fabric with the Velcro to prevent light from leaking out (picture E).
5. Attach and stretch the inner diffuser with the Velcro attachment (picture F).
6. Stretch the outer diffuser between the corners on the softbox, then repeat for each side (picture G). Finally make sure to tight the diffuser all around to prevent light leakage. The outer diffuser should be mounted close to the silver side and not to the softbox outer edge.
7. The softbox is finished and ready to use! (picture H)

